# **ET272**



#### Multi-channel power analyzer



#### Description

Multi-load power analyzer for single or threephase systems installable on DIN rails. Manages current input via one or two groups of split-core current sensors connected with RJ-11 connectors.

The ET272 is equipped with RS485 ports for daisy chain connections.

#### Benefits

- Reduced installation time and errors. Equipped with detachable terminals for all connections. Connected to two groups of split-core current sensors with two cables fitted with RJ-11 connectors. For connections in cascade of multiple ET272s the voltage reference is required only once.
- Installation flexibility. It can be installed in new or existing single- and three-phase systems. Suitable for DIN rail mounting.
- Granular analysis. It provides single-phase or threephase measurements (up to 2 three-phase loads or up to 6 single-phase loads).
- Tamper-proof. The terminals and display can be sealed. • Self detection of primary current of the TCDxM (the dedicated current transformers).
- **Easy identification.** The labels supplied with the instrument guarantee a quick identification and the subsequent commissioning (powered by VMU-C).
- Quick installation. The ET272s automatic addressing (via VMU-C) and configuration guarantee a quick installation. In a Data Center with server racks using power bus-bar trunking system, costly commissioning time can be reduced up to 94%.

#### **Applications**

ET272 is connected directly to current sensors in switchboards for simultaneous monitoring of multiple singleor three-phase loads in low voltage systems.

It's created for both commercial and industrial environments, such as Data Centers: in these contexts, ET272 with VMU-C ensure that an entire Power Distribution Unit (PDU) is monitored.

Moreover, this device guarantees a quick installation thanks to its automatic addressing and configuration through the dedicated function available in the WEB interface of the VMU-C.


Suitable for retro-fit applications and for new installations where more flexibility is required.

#### **Main functions**

- Measurement of energy consumption and main electrical variables of single- or three-phase loads.
- · Single-phase and three-phase measurements.
- · Transmission of data via serial communication.
- · Automatic addressing via VMU-C.



#### **Architecture**




#### Main features

- Up to 2 three-phase loads or 6 single-phase loads managed simultaneously.
- Up to 400 A input current via pre-cabled groups of current sensors (TCDxM) or any primary current of current up to 10000 A sensor with 0.333 V secondary output (via connection adapter TCDMM).
- Single-phase or three-phase measurements: V, A, W/VA/var, kWh, kvarh, PF.
- Accuracy: better than a combination of a class 1 meter and a class 0.5 current transformer.
- · Easy connection function.
- Up to 80 ET272 connected to a VMU-C
- Additional RS485 port for chain connection.
- Self power supply via voltage inputs.
- · Detachable terminals and sealable terminal caps.



#### Structure




Area	Description	
Α	RJ-11 connector for connection to transformer block.	
В	Power supply status LED.	
С	Detachable voltage input terminals.	
D	Detachable RS485 port terminals.	
E	Plastic protection cover or terminals for voltage connection in cascade.	



# **Features**

# General

Material	Noryl, self-extinguishing V-0 (UL 94)
Protection degree	Front: IP40, Terminals: IP20
Terminals	Type: detachable Maximum section: 1.5 mm <sup>2</sup> , Torque: 0.2/0.25 Nm
Overvoltage category	Cat. III
Pollution degree	2
Noise rejection (CMRR)	100 dB, from 48 to 62 Hz
Insulation	See "Input and output insulation"
Mounting	DIN rail
Weight	400 g (packaging included)






Fig. 1 DIN rail

# Environmental specifications

Operating temperature	From -25 to +55 °C/from -13 to +131 °F
Storage temperature	From -30 to +70 °C/from -22 to 158 °F

**Note**: R.H. < 90 % non-condensing @ 40 °C / 104 °F.



### Input and output insulation

Туре	Voltage input and self power supply	Current inputs	RS485 port
Voltage input and self power supply	-	Reinforced *	Double **
Current inputs	Reinforced *	-	Double **
RS485 port	Double **	Double **	-

<sup>\*</sup>By limiting impedance

#### Conformity

Directives	2014/30/EU (EMC - Electro Magnetic Compatibility) 2011/65/EU (Electric-electronic equipment hazardous substances)
Standards	Electromagnetic compatibility (EMC) - emissions and immunity: EN 62052-11 Electrical safety: EN 61010-1 Pulse output: IEC 62053-31, DIN 43864 Metrology: EN62053-21, EN62053-23
Approvals	CE CUSTED UK CA



### **Electrical specifications**

#### **Electrical system and loads**

Managed electrical system	Three-phase with neutral (4-wire)
tem	
Number of loads man-	Up to 2 three-phase loads or up to 6 single-phase loads
aged	

### Voltage inputs

	MV5
Voltage connection	Direct or via VT
Rated voltage L-N (from Un min to Un max)	From 160 to 240 V
Rated voltage L-L (from Un min to Un max)	From 277 to 415 V
Voltage tolerance	-10%, +10%

<sup>\*\*2.5</sup> kV ac 1 min (4 kV pk 1.2/50  $\mu$ s)+ limiting impedance



	MV5
Overload	Continuous: 1.2 Un max
	For 500 ms: 2 Un max
Input impedance	1600 kΩ
Frequency	From 45 to 65 Hz

#### **Current inputs**

Current connection	Only via transformer block TCDxM or TCDMM
	60 A: TCD0M 100 A: TCD1M
Rated current (In)	200 A: TCD2M 400 A: TCD3M
	Up to 10000 A: TCDMM
Minimum current (Imin)	0.02 ln
Maximum current (Imax)	1.2 ln
Start-up current (Ist)	0.002 In
Overload	Continuous: 1.2 In
Input impedance	For 500 ms: 2 In < 0.2 VA

# Power supply

Power supply	Self powered, between L2 and L3
Consumption	2 W, ≤ 4 VA

#### Measurements

Method	TRMS measurements of distorted waveforms
Sampling	1600 samples/s @50 Hz
Sampling	1900 samples/s @60 Hz

#### Available measurements

### Three-phase loads

Energy	Active imported
Current	Phase 1 Phase 2 Phase 3
Voltage	Phase-phase Phase-neutral



Active power	Phase 1 Phase 2 Phase 3 Total load
Power factor	Total load

### Single-phase loads

Energy	Active imported
Current	Phase
Voltage	Phase-neutral
Active power	Total load



# Measurement accuracy

#### ET272

Current			
From 0.05 In to Imax	±(0.5% rdg)		
From 0.02 In to 0.05 In	±(1.0% rdg)		
	Phase-phase voltage		
From (Un min -10%) to (Un max +10%)	From (Un min -10%) to (Un max +10%) ±(0.5% rdg)		
Phase-neutral voltage			
From (Un min -10%) to (Un max +10%) ±(1% rdg)			
Active power (PF=1)			
From 0.05 In to Imax	±(1% rdg)		
From 0.02 In to 0.05 In	±(1.5% rdg)		
Active power (PF=0.5L, 0.8C)			
From 0.1 In to Imax	±(1% rdg)		
From 0.05 In to 0.1 In	±(1.5% rdg)		

### ET272+TCD0M, TCD1M, TCD2M or TCD3M

Current	
From 0.2 In to Imax	±(0.75% rdg)
From 0.05 to 0.2 In	±(1% rdg)
From 0.02 In to 0.05 In	±(1.25% rdg)
Active power (PF=1)	
From 0.2 In to Imax	±(1.25% rdg)
From 0.05 to 0.2 In	±(1.5% rdg)
From 0.02 In to 0.05 In	±(2% rdg)



8

### RS485 port

Protocol	Modbus RTU
Devices on the same bus	Max 160 (1/5 unit load)
Communication type	Multidrop, bidirectional
Connection type	Detachable terminals, 2 wires, maximum distance 1000 m
Configuration parameters	Modbus address (from 1 to 247) Baud rate (9.6) Parity (None / Even)
Configuration mode	Via VMU-C self-addressing function



### **Special functions**

• Measurements independent from direction of current (Easy connection function)



# **Connection Diagrams**

**Note**: for three-phase systems without neutral (3 wires) do not consider the connection to neutral **N**. **Note**: fuses F of 315 mA, if required by local law.




Fig. 2 Voltage and current input connection diagram




Fig. 3 RS485 serial port connection diagram






Fig. 4 Voltage input cascade connection diagram



# References

### ET272DINMV53X2SX (16 total characters)

#### Accessories: order codes

Code	Options	Description
EM270WS V 1T	Replacing the symbol  with the cable length. Lengths available: <b>30</b> , <b>60</b> , <b>90</b> , <b>150</b> , <b>200</b> cm.	Pre-wired cables for voltage connection (one terminal block).
EM270WS V 2T	Replacing the symbol  with the cable length. Lengths available: <b>30</b> , <b>60</b> , <b>90</b> , <b>150</b> , <b>200</b> cm.	Pre-wired cables for voltage connection (two terminal blocks).
EM270WS S 2T	Replacing the symbol  with the cable length. Lengths available: <b>60</b> , <b>90</b> , <b>120</b> , <b>180</b> , <b>230</b> cm.	Pre-wired cables for RS485 connection (two terminal blocks).
EM270WS T V	-	20 detachable terminal blocks for voltage connections.
EM270WS T C	-	20 plastic protection covers for voltage output.
EM270WS T S	-	20 detachable terminal blocks for daisy chain connection of RS485 port.
EM200-96 ADAPTER	-	Adapter to 96 x 96 panel mounting.

### Further reading

Information	Document	Where to find it
Instruction manual	Instruction manual - ET272	www.productselection.net

#### CARLO GAVAZZI compatible components

Purpose	Component name/code key	Notes
Current measurement accessories (mandatory)	TCD0M	See next chapter
	TCD1M	
	TCD2M	
	TCD3M	
	TCDMM	
Configure analyzer via desktop application	UCS configuration software	Available for free download at: www.productselection.net
Monitor data from several analyzers	VMU-C EM	See relevant datasheet

# TCD\_M family

# CARLO GAVAZZI

#### TCD0M, TCD1M, TCD2M, TCD3M for EM271/ET272



# Description

#### •

3-channel split core current transformer block for power analyzer EM271/ET272.

It manages primary current from 60 A to 400 A (depends on the model) and the value is read automatically by the EM271/ET272 to eliminate the need for configuration and calibration by the user

It is equipped with RJ-11 connectors for simple connection to the EM271/ET272.

#### **Benefits**

- 3 split core current sensors
- Primary current from 60 A to 400 A (depends on the model)
- Hole diameter from 9.6 mm to 20.5 mm (depends on the model)
- Connection to the EM271/ET272 with cable with RJ-11 connector
- DIN rail mounting
- · Primary current self-detection




#### **Main functions**

 Conversion of current for input to the power analyzer EM271/ET272.

### • ;

#### **Structure**




Area	Description	
Α	Integrator	
В	Cable with RJ-11 connectors for connection to the EM271/ET272	
С	Split core current sensors	




# **Features**

# General


Material	PC, PA66
Protection degree	IP20
Terminals	RJ-11 connector
Overvoltage category	Cat. III
Pollution degree	2
Insulation	60s 1500 V ac (RJ connectors to housing)
Mounting	DIN rail
	TCD0M: 290 g
Weight (packaging	TCD1M: 360 g
included)	TCD2M: 535 g
	TCD3M: 885 g





31.4

Fig. 5 Integrator (mm)






Fig. 6 TCD0M (mm)

Fig. 7 TCD1M (mm)

46






Fig. 8 TCD2M (mm)




Fig. 9 TCD3M (mm)

# Environmental specifications


Operating temperature	From -25 to +55 °C/from -13 to +131 °F
Storage temperature	From -30 to +70 °C/from -22 to 158 °F


### **Electrical specifications**

Primary current (In)	60 A: TCD0M 100 A: TCD1M 200 A: TCD2M 400 A: TCD3M
Maximum current (continuous)	1.2 ln
Maximum system voltage	0.72 kV ac
Frequency	From 45 to 65 Hz
Accuracy	0.5%
Phase error	≤4°



# **Connection Diagrams**








Fig. 11 RJ11 connections



# References

4	TCD	80	см х
_		•••	O 1111 / 1

Enter the code, replacing the symbol with the selected option (e.g.: TCD 0 M 60 80 CM X).

Code	Options	Description
Т		-
С		-
D		-
	0M60	60 A Primary current
	1M100	100 A Primary current
	2M200	200 A Primary current
	3M400	400 A Primary current
8		-
0		-
С		-
M		-
X	•	-

# Further reading

Information	Document	Where to find it
Instruction manual		www.productselection.net

### CARLO GAVAZZI compatible components

Purpose	Component name/code key	Notes
Measure and display consumption of connected circuits	EM271	-
Measure and display consumption of connected loads	ET272	-

# **TCDMM**



#### 333 mV 3-phase adapter for EM271 / ET272



#### **Benefits**

- Suitable for 3 current sensors (0.333 V)
- Primary current up to 10000 A
- Connection to the EM271/ET272 with cable with RJ-11 connector
- DIN rail mounting
- Screwless terminals



#### **Main functions**

 Conversion of current for input to the power analyzer EM271/ET272.


#### Description

3-phase adapter for power analyzer EM271/ET272.

This manages 3 current sensor (0.333 V output) and the primary value is set by the user via keypad or via software.

It is equipped with RJ-11 connectors for simple connection to the EM271/ET272.

#### **Structure**




Area	Description
Α	Integrator
В	Push-in wire connector
С	Cable with RJ-11 connectors for connection to the EM271/ET272



# **Features**

#### General

Material	PC, PA66
Protection degree	IP20
Terminals	RJ-11 connector
Overvoltage category	Cat. III
Pollution degree	2
Mounting	DIN rail
Weight (packaging included)	80 g






Fig. 12 (mm)

### **Environmental specifications**


Operating temperature	From -25 to +55 °C/from -13 to +131 °F
Storage temperature	From -30 to +70 °C/from -22 to 158 °F


### **Electrical specifications**

Primary current (In)	3x 0.333V
Maximum current (con-	1.2 ln
tinuous)	
Maximum system	0.72 kV ac
voltage	
Frequency	From 45 to 65 Hz



# **Connection Diagrams**








Fig. 14 RJ11 connections



# References



#### Order code



# TCDMM XXX80CM X



### Further reading

Information	Document	Where to find it
Instruction manual		www.productselection.net



### **CARLO GAVAZZI compatible components**

Purpose	Component name/code key	Notes
Measure and display consumption of connected loads	EM271	-
Current sensors 0.333 V secondary output	CTV1X, CTV2X, CTV3X, CTV4X, CTV8X	-
Measure and display consumption of connected circuits	ET272	-



#### COPYRIGHT ©2022

Content subject to change. Download the PDF: www.gavazziautomation.com